



GENERAL NOTES

- WHERE EXISTING OPENINGS ARE TO BE FILLED IN USE THE SAME MATERIALS AND CONSTRUCTION AS THE EXISTING WALL EXCEPT FOR GYPSUM BLOCK WALLS IN WHICH CASE FOLLOW DETAIL (2)
- SEAL ALL OPENABLE TRANSOM WINDOWS CLOSED & REMOVE HARDWARE
- ALL NEW PARTITIONS SHALL EXTEND UP TO THE EXISTING SUSPENDED PLASTER CEILING (SEE DETAIL (3)) EXCEPT AS OTHERWISE SHOWN
- SEE SHEET #34 FOR WALL TYPE SCHEDULE
- PATCH, SEAL, OR PROVIDE FIRE DAMPERS FOR EVERY NEW AND EXISTING OPENING IN THE EXISTING CONCRETE FLOOR SLAB TO MAINTAIN A 1 HR. FIRE RATING

KEYED NOTES

- ALIGN FINISHED FACE OF NEW WALL 5" OUT FROM INSIDE FACE OF EXISTING DOOR OR WINDOW CASING TO CLEAR EXISTING TRIM
- ALIGN FINISHED FACE OF NEW WALL FLUSH WITH EDGE OF EXISTING PILASTER
- CAREFULLY REMOVE EXISTING DOOR, FRAME & TRIM AND SAVE FOR REUSE IN THE PROJECT (SAVE IN PLACE)
- CAREFULLY REMOVE EXISTING TRANSOM WINDOWS & TRIM AND SAVE FOR REUSE IN THE PROJECT
- CENTER NEW WALL ON CENTER LINE OF PREVIOUS MARBLE TOILET PARTITION

ING STUD & GYPSUM BOARD WALL
ING MARBLE TOILET PARTITIONS TO FIT NEW LAYOUT. REMOVE AND SAVE
FITTINGS & WAINSCOTS NOT USED FOR REUSE IN THE PROJECT. SEE SHEET #